GMUND

Gmund Classic

PRINTING TIPS	
Printing	 Offset printing Letterpress Silk-screen printing Blind embossing Hot foil stamping Paper etching Die cutting
Recommendations for offset printing	 Screens up to 80 l/cm Proof printing on same paper stock Under colour reduction when applying strong ink coverage Low absorption of ink, therefore: Use of fully oxidative drying inks Print dusting, low printing stacks Careful drying, a minimum of 24 hours Increase pressure and use soft rubber blankets to achieve optimal covering in the dents of the paper surface when applying area printing
Special advice	 Not suitable for laser and inkjet printers Acid free, pH-neutral The paper surface can vary slightly from making to making Natural papers have a top side and a bottom side. It is recommended, to use the top side as the front side for the print project. For printing and processing, the recommendations of the manufacturers of machines, inks, glues, lamination and embossing foils etc. have to be followed. For any damages caused by improper application, Gmund cannot accept liability. Engraving is an ancient craft. The use of modern textures or metallised papers is a challenge. Tests are recommended prior to starting the print run.
Further information	- world-en.gmund.com

