



Gmund Urban

—

PRINTING TIPS

Printing

- Offset printing
- Letterpress
- Silk-screen printing (Architect and Cement)
- Blind embossing
- Hot foil stamping
- Paper etching
- Die cutting

Recommendations for offset printing

- Screens up to 80 l/cm
- Match litho to the paper colour
- Proof printing on same paper stock
- Under colour reduction when applying strong ink coverage
- Cement and Brasilia: Accumulations of colour and effect pigments cannot be avoided and require frequent cleaning of rubber blankets
- Brasilia: Increase pressure and use soft rubber blankets to allow penetration of the ink into the depths of the embossing

No absorption of ink, therefore:

- Use of fully oxidative drying inks
- Print dusting, low printing stacks
- Careful drying, minimum of 48 hours

Special advice

- Not suitable for laser and inkjet printers
- Acid free, pH-neutral
- The paper surface can vary slightly from making to making
- Natural papers have a top side and a bottom side. It is recommended, to use the top side as the front side for the print project.
- Cement and Brasilia: Metallic hot foil on finished papers may lead to oxidation. Transparent, partial print varnish under the hot foil application can avoid this effect. When applying large motives, this proceeding is recommended.
- Design and printing technique need to be adjusted to the character of the extraordinary paper surface
- For printing and processing, the recommendations of the manufacturers of machines, inks, glues, lamination and embossing foils etc. have to be followed. For any damages caused by improper application, Gmund cannot accept liability.

Further information

- world-en.gmund.com